



415 S Airpark Road  
Cottonwood, AZ 86326, USA  
Phone: (800) 733-0266  
Fax: (928) 649-2306  
Email: info@preclaboratories.com

## Product Technical Fact Sheet

Product Code: CHL-ASSURE

Product Description: Chlor-Assure Chlorine Test Strips 0-200 ppm

Application:

The 0-200 ppm Chlorine test strip is used for testing sanitization and disinfecting levels of free chlorine in water. The Chlorine test strips can be used in facilities where food preparation areas, equipment, and general disinfection are strictly controlled.

Test Range: 0-200 ppm

Test Increments: Color chart calibrated at 25, 50, 100, 150, and 200 ppm using sodium hypochlorite

Accuracy: +/- ½ color chart unit

Detection Limit: 5 ppm

Storage Recommendations:

Store in original packaging in a cool (20-30C), dry, place out of direct sunlight.

Shelf-Life: Two years from date of manufacture when stored properly in original packaging.

Interferences: Test strip may react to other oxidizing materials, peracetic acid, peroxide, etc.

Instructions for Use:

1. Dip the test strip into the solution to be tested for 2 seconds.
2. Remove strip. Do not shake off excess water.
3. After 10 seconds, compare pad against color chart. (Note: color on the pad may not be uniform; this is normal.)

Chemistry Behind the Test:

The test pad is treated with a formula consisting of buffers, surfactants, and red-ox indicators. The presence of free chlorine in a sample causes the red-ox indicator in the test pad to develop color. The intensity of the color developed is proportional to the amount of free chlorine present.

Other Information:

The Chlor-Assure Chlorine test strips were developed to work with solutions prepared from concentrated solutions of sodium hypochlorite.

Disclaimer:

The Chlor-Assure Chlorine test strips are not intended for use to diagnose, treat, or monitor any medical condition.