# TRANS INSTRUMENTS

### HORTICARE LITECHECK OPERATION (MANUAL)

### PRODUCT SPECIFICATION

OPERATING RANGE 100~50,000 Lux 10~5.000 Fc 100Lux / 10 Fc RESOLUTION ACCURACY ±8% FULL SCALE 4x1.5V BUTTON CELL BATTERY

(ALKALINE LR44 OR EQUIV.)

APPROX. 150 HOURS BATTERY LIFE (CONTINUOUS USE)

AUTO SHUT-DEE APPROX. 15 MIN. 0°~50°C OPERATING TEMPERATURE

## LIGHT INTENSITY FOR PLANTS

Plants have an optimal intensity of light. The process of photosynthesis is maximised and plant growth is greatest at this optimal intensity.

If the level of light is less, growth is reduced. In a typical plant, light level of 4000 lux is just enough for the rate of photosynthesis to equal the rate of respiration. This is called the light compensation point. At this intensity, there is no net growth, but the plant can

The control of light intensity allows grower to achieve the desired growth in plants.

Using this light meter, user can control the growth of houseplants by giving just enough intensity, so leaves will not be over grown.

One the other hand, outdoor One the other hand, outdoor plants require intensity higher than the minimum requirements for the plants to flower and bear fruits. Optimal growth is obtained with regular checks and charting of light intensity in different seasons, so growers can make adjustment with correct lighting or shading. correct lighting or shading.



ISO 9001 Certified Firm

S

Z

Ш

STRUM

Z

(J)

Simpl

ወ

ö

use

directional spot sensor -

wide rang

LITECHECK

101

fc with hold function 5,000 0 / 10 50,000 Lux LiteCheck 0 1001 meter Light Intensity orticare

Firm Certified

9001 SO

foot-candle

O

L C X

units in

spot sensor,

directional

to use -

Simple

gital

# Mode Button READ / HOLD BUTTON 0 -BATTERY CAR 0

PRODUCT FEATURE

## BATTERY CAP INSTALLATION

# INSTALLING BATTERY CAP

This unit is shipped with the battery cap open. Close the battery cap by pressing Cap on or a hard surface util the latch clicks. indicating a secure lock.



## REPLACING BATTERIES

- 1. Lift latch with a pen or mini screwdriver. I DO
- 2. Use the thumb to push Cap forward.
- 3. Hold the battery cap and seperate it from the meter.
- 4. Replace all batteries according to polarity.



## PRECAUTIONS IN HANDLING

Do not submerge the unit without the waterproof bag. It cannot come under high pressure underwater and is beyond repair if water gets into the unit

While using the waterproof bag, be sure to fully seal each zip strip, roll up firmly and fasten with the velcro flap before going under water



Do not store unit without the protective cap or under high temperature and direct sunlight. This will shorten the life span of the meter and cause premature expiry of the sensor

Do not clean unit with thinner or solvents This will damage the unit. Use only mild detergent on damp cloth to clean and rinse unit if needed.





# MAKING MEASUREMENT

ntia Palms

Tongue Piggyback Plant Pothos, Devils Ivy

- 1. Press the on-off / HOLD button to switch on the unit. Display will show reading flashing in continuous
- 2. With the Sensor face directed perpendicular to the light source, place meter to position where sensor is just above measuring site and avoid any shadow overcast.
- 3. Keep still and wait for 3 seconds and press the **HOLD** button once to freeze the display. Now you can bring the unit in and take a reading.

This meter measures directional light. The reading displayed indicates lighting accurate at the exact spot where the sensor face is. This reading will appear lower against other photographic/light meter where a dome-shaped sensor is employed to include surrounding reflected stray light from other angles.

- 4. To make another reading, press **on-off** button to release the display and repeat step 3 and 4.
- 5. To avoid inaccurate reading due to shadow overcast, always position the sensor face directed at the light source and away from any shadow.
- 6. To switch off, press and hold-down the on-off button for 3 seconds.

## CHANGING UNITS OF MEASUREMENT

- 1. If different units of measurement is desired, press and hold-down the **MODE** button until the display shows " $L_{JC}$ " for Lux or " $F_C$ " for foot-candle. Then display return to measuring mode.
- 2. Once unit is set, it will remain until you reset it. Each time when the meter is switched on, the word " $L \sigma c$ " or "F c" will appear indicating the unit you are about to measure.

# MAINTENANCE

## LOW BATTERY ALERT

When the battery symbol appear on the display, this indicates a low battery and only 2 hours of continuous use remain. Though the unit may continue to function, the accuracy of the unit will be affected beyond 2 hours. Change the batteries according to instructions overleaf.



transmitters, this product may produce erroneous readings. If this occurs then measurements should be repeated at another location.

# GUIDE TO PLANT LIGHTING CONTROL

Liahtina is necessary for plant arowth. Sufficient lighting is needed for photosynthesis to take place so plants can flower or even bear fruit.

For indoor plants, it is important to use the correct light bulb for artificial lighting with a wide color spectrum. Warm white fluorescent tubes are fairly effective.

Cool white or daylight tubes must be coupled with a few incandescent bulbs of about 3 bulbs to every 10 fluorescent tubes to be effective. Commercially available Metal Halide bulbs alone are most desirable.

As all artificial lighting degrade in intensity over time and it is not noticeable to the eye, it is imperative to check it with the LITEcheck tester periodically. Grower can then adjust light fittings to increase intensity or replace the bulbs if they fail to generate the required intensity.

# How much light is enough?

The amount of light required varies with each plant as listed in the table. In each category, the lower reading is the minimum light required for each plant to sustain life but would not promote growth. Higher reading is always desirable for optimal plant growth and necessary for flowering.

Duration of light exposure are also important and most plants requires 12 to 14 hours of day light or 16 to 18 hours of artificial light.

**High Light Requirement** Low Light **Medium Light** Very High Light Requirement Minimum 30 -50 fc 300~500 Lux inimum 80 ~160 fc 800~1,600 Lux nimum 220 fc 2,200 Lux Minimum 1080 fc / 10.800 Lux ptimum 540 ~ 1080 fo 5,400~10,800 Lux ım 80 -220 fc ım 220 ~540 fc 2,200-5,400 Lux
Plant (Plea)
lant (Pilea)
inia (Begonia)
(Caladium)
(Dizygotheca 800-2,200 Lux t Ferns (Aspleni Lady Palms Parlor or Ge (Saxifraga) Low to Medium Light Requirement Medium to High Light Requirement High to Very High Light Requirement Minimum 30 -50 fc / 300-500 Lux Minimum 80 ~160 fc / 800~1,600 Lux Minimum 220 fc / 2,200 Lux Optimum 220 ~540 fc / 2,200-5,400 Lux (Asparagus) Nerve Plant (Fittoni Optimum Above 1080 fc / 10,800 Lux African Violet Airplane or Spi Aralia Starlite Bromei Creeping Figs ne or Spider Plant

(Episcia)

Fiddle Leaf Figs Indian Laurel Figs

Jade Plant Moses in the Cradle

(Gynura)

(Tradescantia) (Hoya)